


How to Configure and Play Back Dual Stream Recording

Dual Stream is a technology used to record high resolution video on back end device while transmitting a lower resolution stream over the network.


Please note that enabling dual-stream recording will record main and sub stream simultaneously, which will use more space on HDD(s).

On local GUI

Configure: Click Storage- Record-Select the camera –Advanced- Set Stream Type as Dual- Stream, click OK.




Play Back: Go to Playback menu, click switch button at lower right corner to switch between main stream and sub stream.




On Web Browser

Configure: Go to Configuration- Schedule Settings-Record Schedule –choose camera-Advanced-Set Stream Type as Double Stream, click OK.




Play Back: Go to playback menu-choose date and specific stream type, click search.



On iVMS-4200

Configure: After adding device to iVMS-4200, go to Remote Configuration- Basic Setting-Configuration-Schedule Settings-Record Schedule –choose camera-Advanced-Set Stream Type as Double Stream, click OK.



Play Back: Go to Maintenance and Management-Device Management-choose camera channel –edit button-choose Playback stream type.

